

## TEMPERATURE & PRESSURE T&P PLUGS OPERATING INSTRUCTIONS FOR HYDRONIC APPLICATIONS

Specifications Neoprene	Static With Cap On	During Operation With Cap Off
Temperature Range – Continuous	-40°F to 150°F	45°F to 150°F
Maximum Intermittent	200°F	175°F
Pressure	500 psig	400 psig
Nordel		
Temperature Range - Continuous	30°F to 275°F	45°F to 275°F
Maximum Intermittent	275°F	275°F
Pressure	500 psig	400 psig

#### Application:

These T&P plugs are intended for use as an aid in taking pressure or temperature readings. Proper care should be taken to make sure that the T&P plug has been installed in an acceptable manner and that the T&P plug will operate within its specifications.

The T&P plug is suitable for gases and liquids, which are compatible with the neoprene and nordel valve materials. Neoprene and Nordel are unsuitable for use with some gases and liquids. **Check with the manufacturer if you are not sure.** 

Below 45°F the neoprene and nordel valves do not recover their original shape as rapidly as they would at temperatures above 45°F. Therefore, upon removal of the pressure or temperature probe, the valves may not close fully and immediately or the valves may remain slightly open until the operating temperature is above 45°F. Duration of probe insertion and pressure are also factors in the rate of valve closing. For this reason, T&P plugs should not be used in applications where discharging gas or liquids would create a hazard.

The gasketed cap is supplied to eliminate the small amount of leakage that may occur after probe removal. The cap should be left on the T&P plug at all times and tightened to deter unauthorized removal.

Special care should be taken to assure that readings are taken in the shortest space of time and that a probe is **never** left in a T&P plug for a period of hours or days. Severe deformation of the valves may occur if the probe is left in the T&P plug.

The T&P plug should not be installed in the bottom of a vessel or pipe where dirt could collect. Debris may lodge in the T&P plug as the probe is being removed and prevent the valves from closing fully. It is inadvisable to use the T&P plug on gas or liquids that are dirty.

Since some leakage upon removal of the probe is normal, **personal protection equipment MUST BE USED including protective goggles to prevent eye injury.** 

#### **Operating Procedure- Pressure or Temperature Readings:**

- 1) The operator must wear personal protective equipment including protective goggles to avoid dirt or liquids being blown into the eyes during insertion or removal of the probe. Some leakage after removal of the probe is normal.
- Slowly remove the cap from the T&P plug. If, while doing so, you feel or hear gas or liquids escaping, quickly retighten the cap. Determine at this time if the T&P plug has been used improperly and if necessary replace the T&P plug as soon as possible.

Petersen Products • P.O. Box 340 • 421 Wheeler Avenue • Fredonia, Wisconsin 53021-0340 Tel: 800-926-1926 / (262)-692-2416 • Fax: 800-669-1434 / (262)-692-2418 Email: sales@petersenproducts.com • www.petersenproducts.com

# Petersen

- 3) If you have determined that the T&P plug is operating properly, remove the cap and put the cap in a safe place so that you can replace it when you are finished using the T&P plug. **The operator should always carry spare caps.**
- 4) Select the appropriate probe for pressure or temperature. Clean and lubricate the probe with a small amount of petroleum jelly or silicone grease. Examine the probe for any sharp burrs, which could cut the neoprene or nordel valves. Do not try to use non-standard or damaged probes.
- 5) Pressure Probe Insertion: Use Only "Blow Out Proof" Gauges.
  - a) Determine if the T&P plug is above 45°F. Below this temperature the T&P plug may close slowly. The operator should be ready to replace the cap immediately after the reading is taken.
  - b) Examine the insertion hole in the T&P plug and remove any loose debris. This step is important if the cap is missing. If the probe is inserted through loose debris, debris may be carried into the T&P plug and prevent it from sealing when the probe is removed.
  - c) Very slowly, partially insert the lubricated pressure probe into the test T&P plug. Know the pressure behind the T&P plug and be prepared to quickly withdraw the probe before rupturing or over pressuring the gauge. The T&P plug, in its static, state and with out a cap, can easily withstand over 500 psig without leaking. Do not assume that, since the T&P plug is not leaking, that it is safe to quickly and fully insert a low range gauge. If you guess wrong, the pressure gauge could explode. Be sure no personnel are in the blow-out area of the gauge.
  - d) When the pressure gauge needle stops moving up-scale, then fully insert the probe and read the pressure.
  - e) Do not leave the probe in the T&P plug any longer than necessary. The longer the probe is inserted, the longer time it will take for the T&P plug to seal when the probe is removed. Also, the longer you leave the probe in the T&P plug, the more likely you are to forget to remove it and replace the cap before leaving the site. Leaving the site with the probe still in the T&P plug can create a dangerous situation. The danger is that the pressure and temperature can exceed the operating limits which can eject the probe (which will be followed by leakage). Also, the cap is more likely to be lost if the probe is left unattended. See item No.7 for dealing with a probe that has been left unattended.
  - f) When removing the probe, do not place your face near the T&P plug. Always observe safe procedures.
  - g) As soon as the probe is removed, replace the cap. Always carry a spare cap in case you drop one in an inaccessible place or if you simply misplace the cap.

### 6) **Temperature Probe Insertion**:

- a) Temperature probe insertion is similar to pressure probe insertion with the exception that the operator should always first determine the pressure and temperature behind the T&P plug before insertion of the temperature probe. This assures that the T&P plug and thermometer are operating within their specifications limits. After the pressure and temperature have been determined, follow the steps as outlined in items 5a thru 5g.
- 7) Removing A Probe That Has Been Left Unattended: Since the probe could be ejected at any time, restrain the probe or keep face and body away from the axis of the T&P plug. Removal of the probe could result in leakage and if the pressure is above 300 psig, it may be difficult to replace the cap. If the seal leaks, do not remove the probe. Remove the pressure and replace the T&P plug. Discard the old T&P plug.

Contact Petersen with any questions or suggestions relating to the use of any Petersen product.

pp instructions booklet pressure & temp T&P plugs operating instructions PLL Rev. 06/08/2017